



K6858938

1997 WRANGLER TJ GRILLE GUARD INSTALLATION INSTRUCTIONS

82202147-steel-black 82202149-aluminum-silver 82202558-steel-red
82202148-aluminum-black 82202150-steel-chrome 82202711-steel-moss green

NOTE: The above products should be cleaned with a mild detergent and protected with Mopar Cleaner polish #4796237.

| COMPONENTS | | | HARDWARE | | |
|--------------|------------|---------------------------|--------------|------------|------------------------------------|
| <u>ITEM#</u> | <u>QTY</u> | <u>DESCRIPTION</u> | <u>ITEM#</u> | <u>QTY</u> | <u>DESCRIPTION</u> |
| A | 1 | grill guard assembly | 1 | 4 | 1/2" x 1 1/2" button head screw SS |
| B | 2 | 3" x 5 1/4" surlyn gasket | 2 | 4 | 1/2" diameter flat washer SS |
| | | | 3 | 4 | 1/2" diameter surlyn washer |

Hardware Bag contents: B, 1, 2, 3

NOTE: Use anti-seize compound on stainless steel hardware for ease of installation and removal of product.

READ THE FOLLOWING CAREFULLY!

If you have factory installed fog lights and wish to retain them, they must be relocated. To do so, it is necessary to obtain WIRE HARNESS EXTENSION #82203245 from your dealer. Refer to Section (B) below.

INSTRUCTIONS

Section (A)

1. Remove and discard the four 1/2" bolts that fastens the bumper to the frame rails. If vehicle is equipped with tow hooks, remove and store for future use.
2. Carefully position grille guard (A) on top of frame rails and place surlyn gasket (B) between frame and grille guard (A).
3. Coat threads on stainless steel screws (supplied) with anti-seize compound and combine screw with flat washer and surlyn washer to fasten grille guard to top of frame rail. Torque stainless steel bolts to 45 ft-lbs.

Section (B)

1. Remove existing fog lights.
2. Drill a 3/8" hole in the bumper 10 3/8" toward center of vehicle from the existing fog light hole. De-burr and prime with Mopar approved primer.
3. Install fog lights in newly drilled holes and connect lights using wire harness extension.

NOTE: To perform the above operation, the bumper must be removed to allow enough room to install the nut on the fog light post.

FOR INSTALLATION ASSISTANCE CALL 1-800-739-6837