

Convenience Net

Cherokee

Installation Instructions:

This package contains: (1) Pet / Cargo Holder Net,
(2) Screws, (2) Mushroom Anchors, (2) 'D' rings

1. Locate headliner trim screw just rear of the 'C' pillar and remove with a phillips screwdriver. See Figure '1'.
2. Thread supplied longer screw into mushroom anchor and attach to upper trim. See View 'A'.
3. Locate rear seat lock bracket below 'C' pillar. Using a 5/16" wrench, remove top bolt. See Figure '1'.
4. Insert 5/16" bolt into supplied 'D' ring and reassemble to seat lock bracket. See View 'B'. Repeat steps 1 - 4 for opposite side of vehicle.
5. Attach upper cord loop to mushroom anchor in headliner trim, middle steel clip to 'D' ring on rear seat lock bracket, and lower corner steel clip to floor mounted 'D' ring. See Figure '1'. Repeat for opposite side of vehicle.
6. Tighten net by using cinch mechanism at bottom of net.

(For service parts call: 1-800-598-3094)

Figure '1'

